



Kimball & Young

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical furnishing, basic precautions should always be followed, including the following:
Read all instructions before using the furnishing.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

DANGER – To reduce the risk of electric shock.

- 1. Always unplug this furnishing from the electrical outlet before cleaning.

WARNING – To reduce the risk of burns, fire, electric shock, or injury to persons:

- 1. Unplug from outlet before putting on or taking off parts.
- 2. Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.
- 3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 4. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
- 5. Keep the cord away from heated surfaces.
- 6. Never operate the furnishing with air openings blocked. Keep the air openings free of lint, hair and the like.
- 7. Never drop or insert any object into any opening.
- 8. Do not use outdoors.
- 9. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- 10. To disconnect, turn all controls to the off position, then remove plug from outlet.
- 11. This furnishing is intended for commercial use.

CAUTION

Hot surface. Keep away from curtains and other combustible materials.

- Do not touch hot lens, guard, or enclosure
- Contact only switch/plug when turning on.

Do not operate the luminaire with a missing or damaged shield.

Consult a qualified electrician to ensure correct branch circuit conductor.

USER-MAINTENANCE INSTRUCTIONS

- 1. This furnishing is non-lubrication and any other servicing is to be performed by an authorized service representative.
- 2. Take away the cord and use original packing for storage when the furnishing is not in use, and care of the cord while in use.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

SAVE THESE INSTURCTIONS

KIMBALL AND YOUNG
Model: 913x3
Manufacturing Date: MMY

6368 Clark Avenue, Dublin, CA 94568
925.245.9220 – fax: 925.245.9203 – 1.800.639.6864



Kimball & Young

913x3 Rechargeable Battery Mirror

ADDITIONAL SAFETY INSTRUCTIONS – LITHIUM-ION BATTERY

- Do not immerse the battery in water or allow it to get wet.
- Do not use or store the battery near sources of heat such as a fire or heater.
- Do not use any other chargers other than the one provided.
- Do not reverse the positive (+) and negative (-) terminals.
- Do not connect the battery directly to wall outlets or car cigarette-lighter sockets.
- Do not put the battery into a fire or apply direct heat to it.
- Do not short-circuit the battery by connecting wires or other metal objects to the positive (+) and negative (-) terminals.
- Do not pierce the battery casing with a nail or other sharp object, break it open with a hammer, or step on it.
- Do not strike, throw or subject the battery to physical shock.
- Do not directly solder the battery terminals.
- Do not attempt to disassemble or modify the battery in any way.
- Do not place the battery in a microwave oven or pressurized container.
- Do not use the battery in combination with primary batteries (such as dry-cell batteries) or batteries of different capacity, type or brand.
- Do not use the battery if it gives off an odor, generates heat, becomes discolored or deformed, or appears abnormal in any way. If the battery is in use or being recharged, remove it from the device or charger immediately and discontinue use.

CAUTION

Do not use or store the battery where it is exposed to extreme heat, such as under the window of a car in direct sunlight on a hot day, as the battery may be overheated. This can also reduce battery performance and/or shorten service life.

If the battery leaks and electrolyte gets in your eyes, do not rub them. Instead, rinse them with clean running water and immediately seek medical attention.

Use the battery only under the specification of cell. Failure to do so can result in reduced performance or a shortened service life.

SAVE THESE INSTRUCTIONS

KIMBALL AND YOUNG

Model: 913x3

Manufacturing Date: MMY

6368 Clark Avenue, Dublin, CA 94568
925.245.9220 – fax: 925.245.9203 – 1.800.639.6864

Back Page

913x3


Safety Instruction

Dim: 210mm (W) x 297mm (L)




Installation instructions for series 944-2-Xx5HW Series

1. Remove mounting plate by unscrewing the three baseplate cover screws from the mounting assembly.



2. Choose your installation height, using a level use the mounting plate to mark drilling locations, and drill pilot holes.




Changing the Way You See Yourself


800 NE TENNEY RD, STE 110-220, VANCOUVER, WA 98685
TEL: 800-639-6864 AX: 925-254-9203 WEB: WWW.APTATIONS.COM



3. If installing on a stud, use wood screws to fasten the baseplate on the wall. If not installing on a stud use drywall anchors and screws.



4. Place the mirror on the mounting plate, and secure using the three baseplate cover screws .



5. Plug the mirror in using the provided charging cable.